

Architectural Exterior Range

Installation guide for exterior Wall Spot light

JCC | a **LEVITON** company

Important information

- It is recommended that luminaires are installed by a qualified electrician to ensure the installation complies with the local current wiring regulations.
- Any broken or damaged parts should be replaced as soon as possible. JCC will not accept responsibility for claims arising from sub-standard installations.
- These products are designed for connection to a 200-240V~ 50/60Hz supply.
- The light source of this luminaire is not replaceable: When the light source reaches the end of its life, the whole of the luminaire must be replaced.
- This luminaire is suitable for indoor and outdoor use.
- It may be necessary to upgrade your MCBs to allow for increased inrush current.

INSTALLATION


ENGLISH

Specifications Colour temp: 3000K Ra: 80

Product code	Wattage	Lumens	LpcW
JC17042	10W	750	75
JC17043	10W	750	75

200-240V~ 50/60Hz / Class I ⚡




Figure 1. Mains input




- Read instructions and check that you have all of the tools and accessories required to complete the installation correctly. Isolate power supply before starting the installation.

Installation procedure

1. Remove body from base/back plate and use as a template for fixing.
2. Feed cable through grommet, ensuring water tight prior to fixing in desired location.
3. Terminate electrical connections as shown in Fig 1.
4. Refit body and secure with fixings.
5. Turn on supply and test for operation.



Profile & Dimensions



All dimensions in millimetres

Important warranty information

The Architectural exterior range is supported by a 3 year warranty; which must be registered online at jcc.co.uk/warranty.

The installer will be asked to provide the following information, which is detailed on a label attached to the luminaire's chassis: Product Code/Batch Code.